



ARROW REST INSTALLATION

1. Using the 5/16" screw, loosely mount the side bracket to the outside of the bow riser.
2. Insert stem from the roller rest through the hole on the side bracket.
3. Locate center-shot on your bow. Adjust the rest to center and pivot side bracket to desired location.
4. Tighten the 5/16" side bracket screw and secure to bow.
5. Tighten small screw on side bracket to secure and clamp arrow rest.

Note: Because every bow is different, each center shot location will vary. It is possible that the stem of the arrow rest may interfere with accessories. Excess interfering material can be cut off without issue.

